

USB Power Sync Travel Kit

I. Introduction

The Belkin USB Power Sync Travel Kit provides synchronization with your computer while offering safe and convenient charging three different ways.

- 1) The USB Sync Charger charges your handheld while it synchronizes data between your handheld and personal computer
- 2) The USB Cigarette Lighter Adapter allows you to convert the Sync Charger into a car charger—just plug the Sync Charger’s USB connector into the Adapter’s USB port.
- 3) The USB AC Adapter works with the Sync Charger to provide a flexible solution, allowing you to charge from virtually any AC wall plug. Belkin includes US, United Kingdom, European Union, and Australian plug adapters for use abroad.

II. Connecting the USB Sync Charger to a Personal Computer

- Plug the Sync Charger’s USB connector into an available USB port on a desktop or laptop computer.

For Palm™ (fig. 1) and Compaq® iPAQ™ (fig. 2) users:

- Plug the other end of the Sync Charger into the AutoSync connector at the base of the handheld. Be sure that the word “PUSH” is facing up. The handheld will start to charge instantly.




fig. 1




fig. 2

For Hewlett-Packard® Jornada® (fig. 3) users:

- Plug the larger Sync Charger connector into the Jornada sync receptacle and the smaller power connector into the power receptacle at the base of the handheld. The Jornada handheld will start to charge instantly.




fig. 3

- For information about synchronizing your handheld, please refer to the user guide included with your handheld.

III. Connecting the USB Sync Charger to an Automobile’s 12V Power Socket

- Plug the Sync Charger’s USB connector into the USB receptacle in the Cigarette Lighter Adapter included with the Belkin Travel Kit.
- Insert the Adapter in the automobile’s 12V power socket (the cigarette lighter socket) until it is firmly seated.

For Palm and Compaq iPAQ users:

- Plug the other end of the Sync Charger into the AutoSync connector at the base of the handheld. Be sure that the word “PUSH” is facing up. The Sync Charger will snap into place. The handheld will start to charge instantly.

For Hewlett-Packard Jornada users:

- Plug the larger Sync Charger connector into the Jornada sync receptacle and the smaller power connector into the power receptacle at the base of the handheld. The Jornada handheld will start to charge instantly.

Note: For best results, do not start your vehicle while the handheld is connected to the 12V power socket.

IV. Connecting to the USB AC Adapter

- Attach the selected plug adapter to the base of the USB AC Adapter. It will slide on and snap into place.
- Plug the Sync Charger’s USB connector into the USB receptacle in the AC Adapter.
- Plug the AC Adapter into an AC wall socket.

For Palm (fig. 4) and Compaq iPAQ (fig. 5) users:

- Plug the other end of the Sync Charger into the AutoSync connector at the base of the handheld. Be sure that the word “PUSH” is facing up. The Sync Charger will snap into place. The handheld will start to charge instantly.




fig. 4




fig. 5

For Hewlett-Packard Jornada (fig. 6) users:

- Plug the larger Sync Charger connector into the Jornada sync receptacle and the smaller power connector into the power receptacle at the base of the handheld. The Jornada handheld will start to charge instantly.




fig. 6

V. Changing Power Plugs

- Insert the removal tool into the plug adapter’s access socket.
- While pressing the plug forward, *gently* depress the tool into the socket. This will depress the internal latch, allowing the plug adapter to be removed (fig. 7).
- Excessive pressure when using the removal tool could damage the AC adapter. Remove plug adapters carefully.
- Slide the plug adapter up and off.
- Attach the plug adapter of your choice (fig. 8).




fig. 7




fig. 8

VI. Specifications

USB Sync Charger

Weight:	1.5 ounces
Cord Length:	(1.5m) 59 inches

USB AC Adapter

Weight:	6 ounces (with 4 plugs)
Input:	100–240VAC, 50–60Hz, 0.3A
Output:	4–7VDC, 6W
Environmental:	41° F to 95° F (5° C to 35° C)
Safety & Testing:	UL 1950, cUL TUV GS-Mark CE/CISPR 22-approved

Compatibility

Models Supported:

F8Q1002	Compaq iPAQ H3100 series Compaq iPAQ H3600 series Compaq iPAQ H3700 series
F8P3001	Palm m500 Palm m505
F8H1001	Hewlett-Packard Jornada 520 series Hewlett-Packard Jornada 540 series Hewlett-Packard Jornada 560 series

Information

CE Declaration of Conformity

We, Belkin Components, declare under our sole responsibility that the F8Q1002, F8P3001, F8H1001, to which this declaration relate, are in conformity with EN60950 Safety Standard.

Belkin Components Limited Lifetime Product Warranty

Belkin Components warrants these products against defects in materials and workmanship for its lifetime. If a defect is discovered, Belkin will, at its option, repair or replace the product at no charge provided it is returned during the warranty period, with transportation charges prepaid, to the authorized Belkin dealer from whom you purchased the product. Proof of purchase may be required.

This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication; if the product has been modified without the written permission of Belkin; or if any Belkin serial number has been removed or defaced. THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED. BELKIN SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No Belkin dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

BELKIN IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH BELKIN PRODUCTS.

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusions of implied warranties, so the above limitations of exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.



Belkin Components
501 West Walnut Street
Compton • CA • 90220 • USA
Tel: 310.898.1100
Fax: 310.898.1111

Belkin Components, Ltd.
Unit 13 • Gatelodge Close • Round Spinney
Northampton • NN3 8RX • United Kingdom
Tel: +44 (0) 1604678300
Fax: +44 (0) 1604678330

Belkin Components B.V.
Starpac Building • Boeing Avenue 333
1119 PH Schiphol-Rijk • The Netherlands
Tel. +31 (0) 20 654 7300
Fax. +31 (0) 20 654 7349

Belkin Components, Ltd.
7 Bowen Crescent • West Gosford
NSW 2250 • Australia
Tel: +61 (2) 4372 8600
Fax: +61 (2) 4325 4277